



P.O. Box 32 Pismo Beach CA, 93448
SPORTROCKINTL.COM * Ph.805-434-2305 * Fax 805-434-2369

Park Pets Engineered Wood Fiber (EWF) Installation

- SELECT YOUR DESIRED LOCATION FOR THE PARK PET.
- BE SURE GROUND IS STABLE, AND ALL USE-ZONE CRITERIA IS MET.
- USE 2"X10" LUMBER TO FORM A BOX SO THAT THE INTERIOR FORM-BOARD DIMENSIONS ARE 2 INCHES LONGER AND 2 INCHES WIDER THAN THE PARK PET'S LENGTH AND WIDTH.
- STAKE AND LEVEL THE FORM-BOARDS IN THE SELECTED POSITION. USE BLOCKOUTS IF DESIRED. TOP OF FORM-BOARDS SHOULD BE SET APPROXIMATELY 3 INCHES LOWER THAN FINAL DESIRED TOP FINISHED LEVEL OF THE EWF AFTER INEVITABLE, FUTURE COMPACTION.
- FILL FORM WITH A 4-SACK CEMENT SLURRY AND ROD TOP SMOOTH.
- CAREFULLY PLACE PARK PET, WITH ALL FOUR ANCHOR BOLTS INSTALLED TO THE PET, ONTO THE FLAT SLURRY PAD (SLURRY SHOULD NOT BE SO WET THAT PET SINKS). ALL FOUR ANCHOR BOLTS WILL SUBMERGE INTO WET SLURRY MIX.
- CLEAN OFF ANY CONCRETE RESIDUE OFF THE PARK PET WITH CLEAN WATER!
- ALLOW SLURRY TO TIGHTEN UP THEN REMOVE FORMS.
- SHAVE SLURRY AWAY FROM PEREMETER OF THE PARK PET USING A SHOVEL AND TROWEL, LEAVING A 10" FOUNDATION BELOW PARK PET. PLEASE REMEMBER! THE OUTSIDE BOTTOM PEREMETER EDGE OF THE PARK PET MUST SIT FIRMLY ON THIS NEW FOUNDATION IN ORDER TO SATISFY MANUFACTURES WARRANTY!
- SMOOTH ANY ROUGH OR SHARP EDGES OF THE FOUNDATION WITH A SPONGE FLOAT BEFORE INSTALLING EWF.
- ALLOW 7 DAYS CURE PRIOR TO USAGE.

"All Park Pets and Boulders MUST be installed with the resilient "safety" surfacing appropriate to the playground safety guidelines for your city, county, or state."